

FIG. 1




FIG. 2

FIG. 3




FIG. 3




FIG. 4




FIG. 5




FIG. 6





FIG. 9




FIG. 9




FIG. 10

FIG. 11




FIG. 11




FIG. 12




FIG. 14




FIG. 13




FIG. 15




FIG. 16

SETTING OF SLIDE & ROTARY SWITCHES

OPERATING STATES	SLIDE SW1	SLIDE SW2	ROTARY SWITCH				REMARKS
			Pos. #	1	2	3	4
NORMAL (MODEM)	L	L	0, 2, 4, 6	L	x	x	L
NORMAL (AT)	H	L	0, 2, 4, 6	L	x	x	L
MAINTENANCE (MODEM)	L	H	0, 2, 4, 6	L	x	x	L
MAINTENANCE (CPU)	H	H	0, 2, 4, 6	L	x	x	L
INITIALI-ZATION 1	L	L	1, 3, 5, 7	H	x	x	L
INITIALI-ZATION 0	H	L	1, 3, 5, 7	H	x	x	L
RESERVED	L	H	1, 3, 5, 7	H	x	x	L
TEST MODE	H	H	1, 3, 5, 7	H	x	x	L
RESERVED	L	L	8	L	x	x	H
TCI (HCI)	H	L	8	L	x	x	H
RESERVED	L	H	8	L	x	x	H
TCI (L2CAP)	H	H	8	L	x	x	H
RESERVED	L	L	9	H	x	x	H
RESERVED	H	L	9	H	x	x	H
RESERVED	L	H	9	H	x	x	H
RESERVED	H	H	9	H	x	x	H

USER
SETTING

SETTING FOR
MAINTENANCE
OPERATION

SETTING FOR
SHIPMENT

FIG. 17